




- *- Area di lavoro con bracci stab. totalmente estesi
- ** - Area di lavoro con bracci stab. parzialmente estesi
- *- Courbe de travail avec bras stabilisateurs toutes ouvertes
- ** - Courbe de travail avec bras stabilisateurs partiellement ouvertes
- *- Working area with stabilisers booms completely extended
- ** - Working area with stabilisers booms partially extended

Area di lavoro-Courbe de travail-Working area "EAGLE 3526"

5.745.200



INCONCERNI PER LAVORO RENTRE-BOOM-STEEL

